Including model: T3



Owner’s Manual

SAFETY GUIDELINES

The symbols below are used throughout this owner's manual and on the product to identify warnings and important information. It is very important for you to read them and understand them completely.

WARNING! Indicates a potentially hazardous condition/situation. Failure to follow designated procedures can cause either personal injury, component damage or malfunction. On the product, this icon is represented as a black symbol on a yellow triangle with a black border.

MANDATORY! These actions should be performed as specified. Failure to perform mandatory actions can cause personal injury and/or equipment damage. On the product, this icon is represented as a white symbol on a blue dot with a white border.

PROHIBITED! These actions are prohibited. These actions should not be performed at any time or in any circumstances. Performing a prohibited action can cause personal injury and/or equipment damage. On the product, this icon is represented as a black symbol with a red circle and red slash.

Please fill out the following information for quick reference:

Pride Provider: _____

Address: _____

Phone Number: _____

Purchase Date: _____ Serial Number: _____

NOTE: This owner's manual is compiled from the latest specifications and product information available at the time of publication. We reserve the right to make changes as they become necessary. Any changes to our products may cause slight variations between the illustrations and explanations in this manual and the product you have purchased. The latest/current version of this manual is available on our website.

NOTE: This product is compliant with WEEE, RoHS and REACH directives and requirements.

NOTE: This product and its components are not made with natural rubber latex. Consult with the manufacturer regarding any after-market accessories.

Copyright © 2017
INFMANU3784/Rev F/September 2017

LABEL INFORMATION

Product Safety Symbols

The symbols below represent labels used on the product to identify warnings, mandatory actions and prohibited actions. It is very important for you to read and understand these symbols completely. Do not remove these labels from your product. Please note that not all of the symbols may be used on your power lift recliner model.

Pinch/Crush Points Hazard! Do not place objects or appendages in the path of moving parts.

Electrical Hazard

Read and follow the information in the owner's manual.

Maximum weight capacity

Do not connect an extension lead to the AC/DC converter or the battery charger.

This product has been tested and complies to IEC 60601-1-2.

Properly dispose of all electronic components, including the external transformer, hand control, batteries, actuator motors, and wiring. Contact your authorized Pride Dealer for more information.

Do not place objects under power lift recliner. Make sure area is clear of obstructions, including pets and small children, during operation.

Do not place objects under the footrest when power lift recliner is in fully reclined position. Make sure area is clear of obstructions, including pets and small children, during operation.

LABEL INFORMATION

Do not cover or place the external transformer under the chair. Keep in an open, well-ventilated area free from foreign material and away from possible pinch points.

Battery Door Location

Indoor Use Only. Avoid exposure to rain, snow, ice, salt or standing water. Maintain and store in a clean and dry environment.



Class II Equipment

Green LED indicates power to the unit is on.

Degree of protection against electric shock

TABLE OF CONTENTS

SAFETY GUIDELINES.....2

LABEL INFORMATION.....3

I. INTRODUCTION.....6
SAFETY.....6
PURCHASER'S AGREEMENT.....6

II. GENERAL GUIDELINES.....7
MODIFICATIONS.....7
WEIGHT LIMITATIONS.....7
PINCH/CRUSH HAZARDS.....7
DEGREE OF PROTECTION/MODE OF OPERATION.....7
STORAGE AND OPERATION TEMPERATURES.....7
EMI/RFI.....8
SHIPPING AND DELIVERY.....8
MOTOR VEHICLE TRANSPORT.....8

III. YOUR POWER LIFT RECLINER.....9
BODY COMPONENTS.....9
ELECRTICAL COMPONENTS.....10

IV. ASSEMBLY/DISASSEMBLY.....12
POWER LIFT RECLINER ASSEMBLY.....12
POWER LIFT RECLINER PLACEMENT.....13
BATTERY INSTALLATION.....13
REMOVABLE CHAISE PAD DISASSEMBLY.....14

V. OPERATION.....14
OPERATION PRECAUTIONS.....14
HAND CONTROL OPERATION.....14

VI. TROUBLESHOOTING.....17
FREQUENTLY ASKED QUESTIONS.....17

VII. CARE AND MAINTENANCE.....18
FABRIC CARE.....18
ELECTRONICS CARE.....18
DISPOSAL AND RECYCLING.....18

VIII. WARRANTY.....19

APPENDIX.....21

I. INTRODUCTION

Safety

WELCOME to Pride Mobility Products (Pride). The product you have purchased combines state-of-the-art components with **safety**, comfort and styling in mind. We are confident the design features will provide you with the conveniences you expect during your daily activities. Understanding how to **safely** operate and care for this product should bring you years of trouble-free operation and service.

Read and **follow** all instructions, warnings and notes in this manual and all other accompanying literature before attempting to operate this product for the first time. In addition, your **safety** depends upon you, as well as your dealer, carer or healthcare professional in using good judgement.

If there is any information in this manual which you do not understand, or if you require additional assistance for setup or operation, please contact your authorised Pride Dealer. **Failure to follow the instructions, warnings and notes in this manual and those located on your Pride product can result in personal injury or product damage and will void Pride's product warranty.**

Purchaser's Agreement

By accepting delivery of this product, you promise that you will not change, alter or modify this product or remove or render inoperable or unsafe any guards, shields or other safety features of this product; fail, refuse or neglect to install any retrofit kits from time to time provided by Pride to enhance or preserve the safe use of this product.

United Kingdom:
Pride Mobility Products Ltd.
32 Wedgwood Road
Bicester, Oxofordshire OX26 4UL
UK

Australia:
Pride Mobility Products Australia Pty. Ltd.
20-24 Apollo Drive
Hallam, Victoria 3803
Australia

NOTE: If you ever lose or misplace your copy of this manual, contact us and we will be glad to send you a new one immediately.

II. GENERAL GUIDELINES

Your power lift recliner is a state-of-the-art life-enhancement device designed to increase mobility. Pride provides an extensive variety of products to best fit your individual needs. Please be aware that the final selection and purchasing decision regarding the type of power lift recliner to be used is the responsibility of you, the power lift recliner user, if capable of making such a decision, and/or your healthcare professional (i.e., medical doctor, physical therapist, etc.).

MANDATORY! Read and follow the information provided in this owner's manual before attempting to operate your power lift recliner for the first time.

There are certain situations, including some medical conditions, where you will need to practice operating the power lift recliner in the presence of a trained attendant. A trained attendant can be defined as a family member or healthcare professional specially trained in assisting you with performing various daily-living activities while safely operating a power lift recliner.

Below are some precautions, tips and other safety considerations that will help you become accustomed to operating the power lift recliner in a safe manner.

Modifications

Pride has designed and engineered your power lift recliner to provide maximum comfort and utility. However, to prevent personal injury and/or damage to your power lift recliner, you should not modify, add, remove or disable any feature, part or function of your power lift recliner. Unauthorised modifications may also void your product's warranty.

NOTE: Use Pride parts only for all repairs and replacements.

Weight Limitations

Your power lift recliner is rated for a maximum weight capacity. Refer to "Appendix A" for more information.

MANDATORY! Stay within the specified weight capacity of your power lift recliner. Pride will not be held responsible for injuries and/or product damage resulting from failure to observe weight limitations.

Pinch/Crush Hazards

The scissor and lift mechanisms are labeled as pinch/crush point hazards on your power lift recliner. Keep clear of these areas and make sure the path of motion is unobstructed. **See figure 3.1** for pinch/crush point locations.

WARNING! Do not place objects or appendages in the path of moving parts.

Degree of Protection/Mode of Operation

- Class II equipment/Type B protection against electric shock
- Mode of operation—Maximum Duty Cycle: 2 min. ON/18 min. OFF

Storage and Operation Temperatures

- Transportation or storage: -40°C/-40°F to 65°C/149°F
- Operation: 10°C/50°F to 40°C/104°F

II. GENERAL GUIDELINES

Electromagnetic and Radio Frequency Interference (EMI/RFI)

WARNING! Laboratory tests have shown that electromagnetic and radio frequency waves can have an adverse effect on the performance of electrically-powered devices, such as power lift recliners.

Electromagnetic and Radio Frequency Interference can come from sources such as cellular phones, mobile two-way radios (such as walkie-talkies), radio stations, TV stations, amateur radio (HAM) transmitters, wireless computer links, microwave signals, paging transmitters and medium-range mobile transceivers used by emergency vehicles. In some cases, these waves can cause unintended movement or damage to the control system of electrically-powered devices. The power lift recliner user can help prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communications equipment. It is recommended that at least 3 metres (9 feet) of distance be maintained between the power lift recliner and any handheld equipment emitting 10 W or more of output power. Refer to the manufacturer's literature for the handheld device to determine the maximum output power of that device.

Every electrically-powered device has an immunity (or resistance) to EMI. The higher the immunity level, the greater the protection against EMI. Per EMC standards, this product has passed immunity testing and is rated as a Group 1, Class B product, meaning the power lift recliner uses RF energy only for its internal function. Therefore, its RF emissions are very low and are not likely to cause any interference in nearby electronic equipment making the power lift recliner suitable for use in all establishments, including domestic establishments and hospitals.

WARNING! Be aware that cell phones, two-way radios, laptops and other types of radio transmitters may cause unintended movement of your electrically-powered device due to EMI. Exercise caution when using any of these items while operating your power lift recliner.

WARNING! The addition of accessories or components to the power lift recliner can increase the susceptibility of the chair to EMI. Do not modify your power lift recliner in any way not authorised by Pride.

WARNING! Your power lift recliner itself can disturb the performance of other electrical devices located nearby, such as alarm systems.

NOTE: If unintended motion occurs, discontinue use of the power lift recliner. Contact Pride to report the incident.

Shipping and Delivery

Before using your power lift recliner, make sure your delivery is complete as some components may be packaged individually. If you do not receive a complete delivery, please contact your authorised Pride Dealer immediately. Where damage has occurred during transport, either to the packaging or content, please contact the delivery company responsible.

Motor Vehicle Transport

If you will be transporting your power lift recliner in a motor vehicle, individual components (external transformer, etc.) should be secured against slipping. The power lift recliner itself must also be secured against slipping (a possible hazard during vehicle braking).

III. YOUR POWER LIFT RECLINER

Body Components

This section describes the features of your power lift recliner. Carefully review the function and location of each item described.



Figure 3.1 Pride Power Lift Recliner Main Components

III. YOUR POWER LIFT RECLINER

Lift Mechanism: Responds to the hand control commands to position the chair in the sit, stand, recline, incline, footrest up and footrest down positions.

Leg Levelers: Manually rotate up or down in order to stabilise the chair before use (**Fig. 3.2**).

Scissor Mechanisms: Extend or retract to take the chair through the various stages of recline (**Fig. 3.3**).



Figure 3.2 Leg Levelers

WARNING! Pinch/Crush Points Hazard! Be aware that the lift mechanism and scissor mechanisms are a pinch point on the power lift recliner. Keep the following items and similar objects clear of these points when operating the power lift recliner:

- **appendages**
- **small children**
- **pets**
- **wires**
- **oxygen tubes, oxygen tanks, and portable ventilators**
- **loose items, including but not limited to clothing and blankets**
- **electrical power leads**



Figure 3.3 Scissor Mechanism

Electrical Components

Your Pride Power Lift Recliner is equipped with a low voltage DC electrical system that reduces the standard household alternating current of 100V AC - 240V AC to direct current (24/39V DC). The electrical components include the external transformer, batteries (not included) and hand control. Keep these areas free from moisture at all times.

WARNING! Keep all electrical components free from moisture at all times to prevent corrosion and electrical hazards.

External Transformer: Connects to a standard electrical outlet to provide power to the power lift recliner. The transformer is equipped with an LED indicator, which shows green when power to the transformer is on.

The external transformer will also come equipped with mounting brackets that allow the transformer to be mounted to the wall directly under the standard electrical outlet. The screws must be mounted to the wall stud for security. Refer to “Appendix B” for a mounting diagram.

III. YOUR POWER LIFT RECLINER

NOTE: Pride is not responsible for damage due to improper installation.

Batteries: Provide the power needed to return the power lift recliner to an upright or semi-upright position in the event of a power failure. For those models equipped with a battery backup system, the batteries (not included) must be installed into the external transformer. See IV. “Assembly/Disassembly.”

NOTE: The batteries will provide power for only a short period of time after power is removed from the system, so it is important to act quickly in the event of a power failure. Press and hold the STAND button on the hand control as soon as possible. Maintain a steady pressure on the button to avoid excessive draw from the battery and achieve the most amount of lift. Keep in mind that the amount of lift the batteries will be able to provide is affected by user weight and battery condition.

Hand Control: Contains the controls needed to operate the various functions of the power lift recliner. Refer to V. “Operation” for more information. The hand control is equipped with a quick-release connector, which enables the user to detach the hand control from the chair, disabling all functions of the hand control.

IV. ASSEMBLY/DISASSEMBLY

Power Lift Recliner Assembly

Your power lift recliner will be shipped in two pieces: the chair-back and chair base. Minor assembly is required before initial use. Follow the instructions below for proper power lift recliner assembly.

Tools Required:

- 5-mm hex key (1)

Follow these steps to assemble the power lift recliner:

1. Press the FOOTREST UP button on the hand control until the footrest is sufficiently elevated from the ground (**Fig. 5.1**).
2. With the pillow side of the chair-back and the power lift recliner armrests both facing the same forward position, slide the bracket of the chair-back over the bracket on the chair base, aligning the holes in both brackets. Insert the 4 bolts into the bracket holes (**Fig. 4.1**).
3. Press the FOOTREST DOWN button on the hand control until the power lift recliner is in an upright, seated position (**Fig. 5.1**).
4. Remove the clevis pin from the motor mount, located on the back of the power lift recliner box. Place the motor between the motor mount, aligning the holes of the motor with the holes of the motor mount. Insert the clevis pin through the motor mount and motor.

WARNING! You must ensure that the chair-back is properly secured before operating the power lift recliner. Failure to do so may result in personal injury and/or property damage.

WARNING! Make sure that the actuator is turned towards the right (if facing the back of the power lift recliner) to avoid possible damage to any power lift recliner components (Fig. 4.2).

NOTE: Make sure that the clevis pin is properly secured before proceeding with the power lift recliner set-up.



Figure 4.1 Power Lift Recliner Assembly



Figure 4.2 Correct Actuator Positioning

5. Press the INCLINE button and elevate the power lift recliner to its highest position (**Fig. 5.1**). Plug the chair-back motor cable (labeled with a green-A tag) into the green-A slot of the controller box. Plug the chair base motor cable (labeled with a yellow-B tag) into the yellow-B slot of the controller box. The controller box is located underneath the power lift recliner.
6. Press the RECLINE button and return the chair to the upright, seated position before use (**Fig. 5.1**). Zip the chair-back fabric to the chair base.

IV. ASSEMBLY/DISASSEMBLY

Power Lift Recliner Placement

Your power lift recliner should be placed near a standard electrical outlet on dry, level ground where there is ample room to allow for proper operation. Pride recommends that you have the assistance of an attendant when positioning the power lift recliner to avoid the possibility of injury when lifting.

Follow these steps to position the power lift recliner in a safe manner:

1. Place the back of the power lift recliner 76 cm (30 in.) from the nearest obstruction while the chair is in the seated position.
2. Adjust the leg levelers to stabilise the power lift recliner (**Fig. 3.2**).
3. Install the batteries into the external transformer if applicable. Refer to “Battery Installation” for more information.
4. Position the external transformer on the floor in an open, well-ventilated area where it will not be an obstruction, or if equipped, utilise the optional wall mount.
5. Position the low voltage connection cable where it will not be pinched between the frame and the lift mechanism.
6. Connect the low voltage connection cable to the external transformer if it is not already connected.
7. Plug the power lead directly into the electrical outlet. **Do not use an extension lead!**

NOTE: If you discover a problem at any point during the set-up and positioning of your power lift recliner, stop and contact your authorised Pride Dealer immediately. To avoid personal injury and/or product damage, do not plug the unit into the electrical outlet until the problem is corrected and do not attempt to fix electrical problems by yourself.

Battery Installation

Your power lift recliner will be equipped with a battery backup system that will activate during a power failure. The backup system is powered by two 9V batteries (not included) that need to be installed into the external transformer.

Follow these steps to install the batteries:

1. Unplug the external transformer power lead from the electrical outlet.
2. Open the marked battery door on the external transformer.
3. Install two 9V batteries into the external transformer (**Fig. 4.3**).
4. Replace the battery door.

NOTE: Always make sure the external transformer is equipped with two fresh 9V batteries, since the battery backup system does not recharge itself. Fresh batteries are defined as 9V alkaline batteries that are replaced every time the battery backup system is activated during a power failure, or once a year if the battery backup system has not been activated.



Figure 4.3 Power Lift Recliner Battery Backup Location

NOTE: If you unplug your power lift recliner for an extended period of time (more than one hour), remove the batteries from the external transformer. The power lift recliner will draw power from the batteries even when it is not in use.

Removable Chaise Pad Disassembly

The chaise pad attaches to the power lift recliner with reusable fasteners to make servicing the chair more convenient.

NOTE: The power lift recliner must be in the recline position in order to remove or attach the chaise pad.

To remove the chaise pad, loosen the front portion of the footrest and remove the chaise pad from the power lift recliner (**Fig. 4.4**).



Figure 4.4 Removable Chaise Pad Disassembly

V. OPERATION

Operation Precautions

There are certain precautions that should be taken during the operation of your power lift recliner. Read and follow these precautions carefully in order to ensure safe power lift recliner operation and to prevent injury and/or product damage.

- Plug the power lead directly into the electrical outlet. **Do not use an extension lead!**
- Do not place anything (e.g., a drinking glass) on top of or near the external transformer.
- If the external transformer box or hand control requires cleaning, unplug the power lead from the electrical outlet and use a clean, dry cloth or lightly dampened cloth. Allow ample drying time before plugging the power lead back into the electrical outlet.
- Periodically check the hand control and all power leads for visible damage.
- Keep the hand control away from all heated surfaces.
- Ensure the hand control is out of the way before sitting in the chair.
- Keep children and pets away from all moving parts while operating the power lift recliner.
- Do not allow children to play on or operate the power lift recliner. Only the intended user should operate the power lift recliner.
- Keep the hand control locked or utilise the quick-disconnect feature on the standard hand control when the power lift recliner is not in use to prevent unintended operation of the chair.
- Avoid pinch points, such as the lift and scissor mechanisms. Keep hands and feet clear of these areas.
- Always leave the power lift recliner in an upright and closed position when not in use.
- Do not sit or stand on the footrest.
- Do not “drop” into the power lift recliner when sitting if it is in a partially raised position.

PROHIBITED! Do not place objects under the power lift recliner or footrest. Make sure area is clear of obstructions, including pets and small children, during operation.

WARNING! Prevent the risk of electrical shock, fire, falls and/or being pinched. Follow all instructions and precautions provided.

WARNING! Prevent potential equipment damage! Do not place the external transformer under the power lift recliner.

WARNING! Do not cover the external transformer. Keep the transformer in an open, well-ventilated area free from foreign material/debris to ensure proper operation.

Hand Control Operation

The hand control is equipped with buttons that control the movement of the chair-back, chair base and footrest (**Fig. 5.1**).

WARNING! Do not lean on or apply downward force to the chair-back when the power lift recliner is in the fully reclined position. Doing so could cause the power lift recliner to tip, resulting in personal injury and/or product damage.

WARNING! Do not use the footrest as a seat, or for purposes outside its intended use. Doing so could cause instability in the power lift recliner and place undue stress on power lift recliner components, resulting in personal injury and/or product damage.

V. OPERATION

Hand Control Operation

Follow these steps to sit in your power lift recliner (Fig. 5.1):

1. Press and hold the STAND button to raise your power lift recliner from the seated position to the standing position.
2. Back into the power lift recliner and sit in the centre of the seat, using the armrests for support if needed.
3. Press and hold the SIT button to lower your power lift recliner to a comfortable seated position.

Follow these steps to recline your power lift recliner from the seated position (Fig. 5.1):

1. Press and hold the RECLINE button until comfortably reclined.
2. Press and hold the INCLINE button to return to an upright, seated position.

Follow these steps to stand up from your power lift recliner (Fig. 5.1):

1. Press and hold the STAND button to raise your power lift recliner.
2. Release the STAND button when the power lift recliner reaches a height where you can stand up comfortably.

NOTE: The hand control on your power lift recliner is equipped with an LED that indicates power to the hand control. If this LED is not lit when the hand control is in use, contact your authorised Pride Dealer.



Figure 5.1 Hand Control

Follow these steps to raise or lower the footrest while in the seated or reclined position (Fig. 5.1):

1. Press and hold the FOOTREST UP button until the footrest reaches a comfortable height.
2. Press and hold the FOOTREST DOWN button to lower the footrest.

Follow these steps to stand up from your power lift recliner from the seated position (Fig. 5.1):

1. Press and hold the STAND button to raise your power lift recliner.
2. Release the STAND button when the power lift recliner reaches a height where you can stand up comfortably.

WARNING! Do not attempt to stand up until you can stand safely, are steady on your feet, and can bear weight. Pride recommends the use of assistance aids and/or an attendant for enhanced stability.

WARNING! Avoid putting all of your weight on the chair armrests when attempting to stand and do not use the armrests for weight bearing purposes.

V. OPERATION

Follow these steps to recline your power lift recliner to the "Trendelenburg" position (Fig. 5.1):
1. Press and hold the FOOTREST UP button until your feet are sufficiently elevated from the ground.
2. With the footrest elevated, press and hold the RECLINE button until your feet are elevated higher from the ground than your head.
3. Press and hold the INCLINE button to return to an upright, seated position.
4. From the upright, seated position, press and hold the FOOTREST DOWN button to lower the footrest.

NOTE: The "Trendelenburg" position is designed to elevate the legs above the head.

Follow these steps to recline your power lift recliner to the "zero gravity" position (Fig. 5.1):
1. Press and hold the FOOTREST UP button until your feet are sufficiently elevated from the ground.
2. With the footrest elevated, press and hold the RECLINE button until your thighs and lower legs are positioned slightly higher than your torso, putting your body in a "V-like" position.
3. Press and hold the INCLINE button to return to an upright, seated position.
4. From the upright, seated position, press and hold the FOOTREST DOWN button to lower the footrest.

NOTE: The "zero gravity" position is designed to disperse body weight evenly across the chair.

NOTE: Pressing and holding the STAND button from any reclined position will bring your power lift recliner back to its upright, seated position and/or stand position.

Keylock

Your hand control may be equipped with a keylock feature (**Fig 5.1**). The keylock feature is intended to disable the functions of the hand control to prevent unintended movement when the power lift recliner is occupied, but stationary, as well as when the power lift recliner is left unattended. The key should only be inserted into the hand control when the position of the power lift recliner needs to be adjusted by the user.

Follow these steps to operate the keylock (Fig. 5.1):
1. Remove the key from the side of the hand control to disable all functions of the hand control.
2. Reinsert the key to restore hand control function.

WARNING! Prevent unintended movement and/or injury. Remove the key from the hand control once the power lift recliner is positioned to the desired setting by the user and any time the power lift recliner is left unattended.

NOTE: As an added safety measure, Pride recommends that you utilise the quick disconnect to remove the hand control from the power lift recliner and store the hand control out of the reach of children when the chair is left unattended.

VI. TROUBLESHOOTING

Your power lift recliner is a state-of-the-art life-enhancement device designed to enhance your mobility. Your power lift recliner should bring you years of trouble-free service; however, it may require occasional troubleshooting. The following troubleshooting tips and FAQs should summarise what you need to know about your power lift recliner. If at any time you do not feel comfortable performing the troubleshooting steps listed in this manual, contact your authorised Pride Dealer for service. Please have the model number, serial number and nature of the problem when calling.

Frequently Asked Questions

What if my power lift recliner does not operate at all?

- Ensure the external transformer is plugged into a properly wired electrical outlet.
- Check the circuit breaker box connected to the electrical outlet.
- Ensure the low voltage connection cable is plugged into the external transformer.
- Ensure the hand control and motor(s) are plugged in properly.
- Ensure the low voltage connection cable is plugged into the motor(s).
- Check the fuse in the power lead. Replace if necessary.

WARNING! The replacement fuse must exactly match the rating of the fuse being replaced. Failure to use properly rated fuses may cause damage to the electrical system.

What if my power lift recliner operates in one direction only?

- Check the STAND/SIT buttons on the hand control to make sure they do not stick. If either button is sticking, the hand control may need to be replaced.
- Contact your authorised Pride Dealer for further assistance.

What if my power lift recliner stops during a lifting cycle?

- Your power lift recliner is equipped with an internal thermal shutoff switch located inside the external transformer that prevents the motor control box from overheating. If the thermal shutoff activates, allow the power lift recliner to remain in a stationary position for 10 minutes to allow the motor to cool, then resume normal operation. If you notice the motors overheating frequently, contact your authorised Pride Dealer.
- There may have been a power failure and/or there are no batteries in the external transformer or the batteries have no charge. Always make sure there are fresh 9V batteries in the external transformer if equipped with battery backup.
- Check the circuit breaker box connected to the electrical outlet.

What if my power lift recliner is rocking from corner to corner after I position the chair?

The floor may be uneven or the carpet may be affecting chair position. Adjust the leg levelers in the area where the chair is rocking. See III. “Your Power Lift Recliner” for instructions on leveling your chair.

Where can I place the external transformer box?

- On the floor away from heat sources in an open, well-ventilated area where it will not be an obstruction.
- On the wall away from heat sources using the optional external transformer wall mount.

Where do I find the serial number on my power lift recliner?

You can find the serial number in two locations—one is near the rear of the motor on the steel lift mechanism, and the second is attached to the frame below the scissor mechanisms. The model number for your power lift recliner is printed below the serial number bar code.

Who do I call for service?

Contact your authorized Pride Dealer for service.

VII. CARE AND MAINTENANCE

Your Pride Power Lift Recliner will require routine maintenance checks. You can perform some of these checks, but others may require assistance from an authorised Pride Dealer. By following the maintenance checks in this section as scheduled, you can help ensure your power lift recliner gives you years of trouble-free operation. If you have any questions regarding your power lift recliner's care, contact your authorised Pride Dealer.

Fabric Care

- Inspect the fabric on a regular basis for any pulls, tears or gaps.
- Your power lift recliner fabric is made of 100% polyester and falls under cleaning code W. Frequent vacuuming and light brushing to remove dust and grime is the recommended cleaning method for your power lift recliner. If spot cleaning is required, you should use the foam from water-based cleaning agents such as mild detergent or non-solvent upholstery shampoo. Apply the foam with a soft brush in a circular motion and vacuum when dry. Pretest a small area of the fabric with the cleaning agent before using this method. If your power lift recliner fabric is in an overall soiled condition, use a professional furniture cleaning service.

WARNING! Fabric should not be allowed to come in direct contact with any type of heat source (e.g., a space heater or cigarette). Personal injury or fire damage may occur.

WARNING! Pride strongly recommends that you do not smoke cigarettes while seated in or using your power lift recliner, although the power lift recliner has passed the necessary testing requirements for cigarette smoking. You must adhere to the following safety guidelines if you decide to smoke cigarettes while seated in or using your power lift recliner.

- **Do not leave lit cigarettes unattended.**
- **Keep ashtrays a safe distance from the power lift recliner.**
- **Always make sure cigarettes are completely extinguished before disposal.**

NOTE: Do not use solvent-type cleaners to spot clean. Do not saturate the fabric. Prevent damage to the fabric; do not expose the power lift recliner to direct sunlight.

Electronics Care

- Inspect all wiring harnesses to make sure they are not damaged or frayed.
- If damage is present, unplug the power lift recliner and contact your authorised Pride Dealer for service.
- Keep all electronics free from moisture and temperature extremes. **Pride Power Lift Recliners are intended for indoor use only!**

WARNING! Even though the power lift recliner has passed the necessary testing requirements for ingress of liquids, you should keep electrical connections away from sources of dampness, including direct exposure to water or bodily fluids and incontinence. Check electrical components frequently for signs of corrosion and replace as necessary.

Disposal and Recycling

Your power lift recliner must be disposed of according to applicable local and national statutory regulations. Contact your local waste disposal agency or authorised Pride Dealer for information on proper disposal of power lift recliner packaging, metal frame components, fabric, electronic components and batteries.

WARNING! Plastic bags are a suffocation hazard. Dispose of plastic bags properly and do not allow children to play with them.

VIII. WARRANTY

Two-Year Limited Warranty

For two (2) years from the date of purchase, Pride will repair or replace at our option to the original purchaser any of the following parts found upon examination by an authorised representative of Pride to be defective in material and/or workmanship:

- Steel Frame
- Motors
- Hand Control
- Scissor Mechanisms
- Steel Lift Mechanism

NOTE: Pride reserves the right to replace only the part of the steel lift mechanism that may be defective.

Not Covered Under Warranty

The following parts are classed as wear items, which may under normal wear and tear require replacing. These items are **not**, therefore, covered under warranty: all fabric. Warranty will also be refused if damage is deemed to have been caused through misuse or accident for which Pride Mobility Products cannot be deemed responsible.

NOTE: Pride Mobility Products provides parts only under warranty. Your authorised Pride Dealer is responsible for labour and service. Please contact your authorised Pride Dealer for information about these services and for any applicable charges.

Australia Only:

NOTE: Pride Mobility Products Australia Pty. Ltd provides only parts under warranty. Your Pride Provider is responsible for labour and service. Please contact your Pride Provider for information about these services and for any applicable charges.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or a refund for a major failure and compensation for any reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

APPENDIX A

POWER LIFT RECLINER WEIGHT CAPACITY	
Model Number	**Rated Weight Capacity**
T3	170 kg (27 stone/375 lbs.)

MANDATORY! Stay within the specified weight capacity of your power lift recliner. Exceeding the weight capacity voids your Pride Power Lift Recliner warranty.

APPENDIX B

External transformer optional wall mount diagram
Hold the transformer on the wall where you intend to mount it, and either mark the holes or drill (as shown) to secure the transformer to the wall.

NOTE: Transformers can vary by supplier. If the transformer supplied with your power lift recliner differs from what is shown below, the transformer and drill points can be outlined and used as a template for wall mounting.



USA
182 Susquehanna Avenue
Exeter, PA 18643-2694

Canada
5096 South Service Road
Beamsville, Ontario L0R 1B3

Australia
20-24 Apollo Drive
Hallam, Victoria 3803
www.pridemobility.com.au

New Zealand
38 Lansford Crescent
Avondale
Auckland, New Zealand 1007
www.pridemobility.co.nz

UK
32 Wedgwood Road
Bicester, Oxfordshire OX26 4UL
www.pride-mobility.co.uk

B.V.
(Authorised EU Representative)
Castricummer Werf 26
1901 RW Castricum
The Netherlands
www.pride-mobility.nl

Italy
Via del Progresso, ang. Via del Lavoro
Loc. Prato della Corte
00065 Fiano Romano (RM)
www.pride-italia.it

France
26 rue Monseigneur Ancel
69 800 Saint-Priest
www.pridemobility.fr

Spain
Calle Velazquez 80 6D
28001 Madrid

www.pridemobility.com

Your Chair has gone through a stringent inspection protocol to ensure our product is made to your satisfaction.

☐ **Upholstery Workmanship**

☐ **Aesthetics and Comfort**

☐ **Performance**

Pride keeps a more detailed report on file at the factory.

Date Inspected

Inspector

Serial #

UDI Label (if applicable)